§401.92

§ 401.92 Wintering and lying-up.

No vessel shall winter within the Seaway or lie-up within the Seaway during the navigation season except with the written permission of the Corporation or the Manager and subject to the conditions and charges that may be imposed.

[39 FR 10900, Mar. 22, 1974, as amended at 65 FR 52915, Aug. 31, 2000]

§ 401.93 Access to Seaway property.

- (a) Except as authorized by an officer, no person shall load or unload goods on property of the Corporation or the Manager.
- (b) Except as authorized by an officer or by the Seaway Property Regulations or its successors, no person shall enter upon any land or structure of the Manager or the Corporation or in any Seaway canal or lock area.

[39 FR 10900, Mar. 22, 1974, as amended at 65 FR 52915, Aug. 31, 2000; 72 FR 2620, Jan. 22, 2007]

§ 401.94 Keeping copies of regulations.

- (a) A copy of these Regulations (subpart A of part 401), a copy of the vessel's valid Vessel Inspection Report and the Seaway Notices for the current navigation year shall be kept on board every vessel in transit. For the purposes of this section, a copy may be kept in either paper or electronic format so long as it can be accessed in the wheelhouse.
- (b) Onboard every vessel transiting the Seaway a duplicated set of the Ship's Fire Control Plans shall be permanently stored in a prominently marked weather-tight enclosure outside the deckhouse for the assistance of shore-side fire-fighting personnel.

[70 FR 12973, Mar. 17, 2005, as amended at 75 FR 10690, Mar. 9, 2010]

§ 401.95 Compliance with regulations.

The master or owner of a vessel shall ensure that all requirements of these Regulations and Seaway Notices applicable to that vessel are complied with.

[70 FR 12973, Mar. 17, 2005]

NAVIGATION CLOSING PROCEDURES

§ 401.96 Definitions.

In §410.97:

- (a) Clearance date means the date designated in each year by the Corporation and the Manager as the date by which vessels must report at the applicable calling in point referred to in \$401.97(c) for final transit of the Montreal-Lake Ontario Section of the Seaway;
- (b) Closing date means the date designated in each year by the Corporation and the Manager as the date on which the Seaway is closed to vessels at the end of the navigation season;
- (c) Closing period means the period that commences on the date designated in each year by the Corporation and the Manager as the date on which the closing procedures in §401.97 apply and that ends on the closing date;
- (d) Montreal-Lake Ontario Section of the Seaway means the portion of the Seaway between the Port of Montreal and mid-Lake Ontario;
- (e) Wintering vessel means a vessel that enters the Seaway upbound after a date designated each year by the Corporation and the Manager and transits above Iroquois Lock.

(68 Stat. 92–97, 33 U.S.C. 981–990, as amended and sec. 104, Pub. L. 95–474, sec. 2, 92 Stat. 1472; 68 Stat. 93–96, 33 U.S.C. 981–990, as amended and secs. 4, 5, 6, 7, 8, 12 and 13 of sec. 2 of Pub. L. 95–474, 92 Stat. 1471)

[47 FR 51124, Nov. 12, 1982, as amended at 65 FR 52915, Aug. 31, 2000; 74 FR 18995, Apr. 27, 2009]

§ 401.97 Closing procedures and ice navigation.

- (a) No wintering vessel shall return downbound through the Montreal-Lake Ontario Section of the Seaway in the same navigation season in which it entered the Seaway unless the transit is authorized by the Corporation and the Manager.
- (b) No vessel shall transit the Montreal-Lake Ontario Section of the Seaway during the closing period in a navigation season unless
- (1) It reports at the applicable calling in point referred to in paragraph (c) of this section on or before the clearance date in that navigation season; or